

# Calibration With Splash Guard (Option -S)

**ITEMS REQUIRED TO CALIBRATE A GAS DETECTOR WITH A SPLASH GUARD USING A 34L, 58L, 78L OR 103L CYLINDER OF GAS:**



NUMBER	FUNCTION	PART NUMBER
1	Orange calibration adapter cup for splash guard. Must be held over splash guard while flowing gas. Comes with tubing attached (see 2)	CET-4700-SCC
2	Standard tubing (approx 61 cm / 2 ft long) included and attached to calibration adapter plug	n/a
3	Regulator for fixed flow @0.5 LPM. Fits 34 L, 58 L, 74 L, and 103 L cylinders	REG-0715-CR2
4	Span Gas / Zero Gas cylinder, with air balance or nitrogen balance (electrochemical sensors), with air balance only (catalytic sensors)	various